

PARTS LIST

NO	Parts Name/名称		材料/Material		
1	尘仓头	Dust compartment nozzle	ABS		
2	透明尘仓	Dust compartment	Transparent ABS		
3	左壳体	Left main body	ABS		
4	右壳体	Right main body	ABS		
5	φ3*12的螺丝	φ3*12 screw			
6	左壳面板	Left Exhaust air cover	Chromed metal		
7	φ3*8的螺丝	φ3*8 screw			
8	右壳面板	Right Exhaust air cover	Chromed metal		
9	防水罩	Outer filter	ABS		
10	防水罩附件	Part on outer filter	ABS		
11	海帕带海帕支架密封圈	HEPA	Cloth		
12	电机支架前密封圈（小圈）	Front sealed circle for motor holder	PVC		
13	电机支架	Motor bracket	ABS		
14	风叶	Fan	ABS		
15	φ3*8机订螺丝	φ3*8 screw			
16	电机	Motor			
17	装饰面板	Decorate plate	ABS		
18	线路板	PCB board assembly			
19	φ2.5*5螺丝	φ2.5*5screw			
20	搭扣	Release button for dust compartment	ABS		
21	拨扭	ON/OFF switch button	ABS		
22	搭扣弹簧（内径φ8.5*23*φ1MM）	Spring for release button			
23	底座	Charger Base	ABS		
24	DC头固定件	DC fix holder	ABS		
25	充电适配器	Adaptor			
26	吸水刷	Squeegee	PVC		
27	毛刷	Brush tool	ABS		
28	扁刷	Crevice tool	ABS		
29	黑色过滤棉	Sponge filter	Sponge		
30	φ3*8螺丝	φ3*8 screw			
31	电池固定件	Battery fixer	PP		
32	电池组	Battery pack			

Vacuum cleaner Model No: BR-2201BD
Explore View

